

## Vertical Platform Lifts from Harmar

Harmar's design team has engineered a line of VPLs that offer safe, smooth access for elevation changes ranging from 4 to 6 feet. With an unobtrusive, small footprint, these lifts provide a practical solution for homeowners, with very little required maintenance.

### The Harmar VPL highlights many safety features:

- Folding ramp allows easy entry and exit and adds stability and security
- Safety sensors detect obstacles and stop the lift, preventing damage to the lift or other objects
- Simple, safe-to-use controls
- Rugged and weather resistant

Harmar has taken care to design a VPL that meets ASME safety design standards. Weather resistant construction means that a Harmar VPL is an ideal solution for both indoor or outdoor settings. The residential model features a 600 pound weight capacity and can be used with most wheelchairs, power chairs and scooters.



**Indoors or outdoors...  
Cost efficient accessibility  
for your home.**



# HARMAR RESIDENTIAL VERTICAL PLATFORM LIFTS



- 4" x 5" constant pressure paddle control
- Seal-Kor powder coat with stainless steel hardware for outdoor use

SPECIFICATIONS	RESIDENTIAL VPL
Capacity	750 lbs. (340.2 kg.)
Drive	ACME screw; 90V ¾ HP fully sealed DC gear motor
Power	115 VAC – 15 Amp circuit breaker
Control Circuit	24 VAC (Low Voltage Controls)
Platform Sizes	<ul style="list-style-type: none"> <li>• VPL400-VPL600: 36" x 48" clear platform</li> <li>• VPL800-VPL1400: 36" x 54" clear platform</li> </ul>
Footprint	50" x 70"
Speed	10.4 fpm
Controls	Emergency stop button in platform
Manual Lowering	Provided
Standards	<ul style="list-style-type: none"> <li>• ETL listed</li> <li>• CSA B44.1/ASME A17.5</li> <li>• Safety standard ASME A18.1</li> <li>• Rated commercial and residential</li> </ul>
Safety Features	<ul style="list-style-type: none"> <li>• Safety pan beneath platform</li> <li>• 4-LED indicators in top cap</li> <li>• Overspeed brake</li> <li>• Overload protection</li> <li>• Interlocks for doors/gates</li> </ul>
Warranty	3-Year Limited



1 Year Limited Warranty  
on New Equipment Installs

An independently owned and operated franchise business.

- ✓ Stair Lifts
- ✓ Vertical Platform Lifts
- ✓ Pool Lifts
- ✓ Patient Lifts
- ✓ Ramps
- ✓ Auto Lifts
- ✓ Bath Modifications
- ✓ Commercial
- ✓ Residential
- ✓ And More